

How to view Device Status & Photo Storage Status?

Answer:

Device Status

1. Click **Setup > Common > Basic Info**.

Basic Info	
Model	IPC
Firmware Version	IPC
Hardware Version	A
Boot Version	V1.0
Serial No.	2102335CC3531740100232
Network	192.168.1.13/255.255.255.0/192.168.1.1
MAC Address	48:ea:63:4d:56:88
Status	
System Time	2018/1/25 19:16:27
Operation Time	0 Day(s) 0 Hour(s) 0 Minute(s)
Intelligent Server	Offline

2. Click **Refresh** for the latest status information.

3. View the device information.


Note: You may view device model, firmware version, intelligent server status, etc, on the basic info page.

Photo Storage Status

View the current photo storage status. See Memory Card Storage for the full storage policy.

Note: Only models with storage function support this function. Please see the actual model for details.

1. Click **Photo**.



2. Click **Refresh** to update the storage status.

3. You can export or delete photos in the **Image List** area.

TAGS:

Common setup, basic setting, refresh status, device information, memory card storage, check status



"Your Reliable Integrated Video Surveillance Solutions Provider"

Shenzhen Starlink Technology Co., Ltd.

1811, Block A, Zhantao Technology Building, Longhua District, P.R.China 518131

Email: info@qixingtechnology.com; qixing@qixingtechnology.com

<http://www.qixingtechnology.com>

©2009-2018 Shenzhen Starlink Technology Co., Ltd. All rights reserved.

*Product specifications and availability are subject to change without notice.