Your reliable integrated video surveillance solutions

How to set Device Mounting Height?


Answer:

Enter the actual height from the installed infrared dome to the ground, so that the dome will be able to automatically adjust its infrared lamp.

Note: Only some certain infrared cameras support this function. Please see the actual model for details.

1. Click Setup > System >


Maintenance.



- 2. Enter the actual height from the installed Infrared Dome to the ground.
- 3. Click OK.

TAGS:

Height, infrared camera, infrared lamp, dome, system maintenance, mounting





"Your Reliable Integrated Video Surveillance Solutions Provider"

Shenzhen Starlink Technology Co. ,Ltd.

1811, Block A, Zhantao Technology Building, Longhua District, P.R.China 518131

Email: info@qixingtechnology.com; qixing@qixingtechnology.com

http://www.www.qixingtechnology.com

©2009-2018 Shenzhen Starlink Technology Co.,Ltd. All rights reserved.

*Product specifications and availability are subject to change without notice.