

Your reliable integrated video surveillance solutions

How to set Iris & Lens Mode?

Answer:

Note: Only some certain network box camera support this function. Please see the actual model for details.

Note: Please use the lens with P-Iris control mode, and connect the iris control cable to the Z/F port of the camera.

Note: Iris can be set only when Lens Mode is set to P-IRIS.

1. Click **Setup > Image > Image** and then click **Advanced**.

The screenshot shows the 'Advanced' settings window. On the left, there are 'Defog' and 'Defog Intensity' settings. 'Defog' is set to 'Off' and 'Defog Intensity' is set to '5'. On the right, there are 'Lens Mode', 'Aperture Control', and 'F-Number' settings. 'Lens Mode' is set to 'P-IRIS', 'Aperture Control' is set to 'Manual', and 'F-Number' is set to '100'. There is a 'Use Recommended Value' button at the bottom right.

2. Modify the settings as required. The following table describes some major parameters.

Parameter	Description
Lens Mode	Z/F: to modify focus and zoom. P-Iris: to modify iris value.
Aperture Control	Automatically or manually adjust iris. Note: You can set this parameter only when Lens Mode is set to P-Iris .
F-Number	Change aperture manually.

3. To restore the default settings, click **Default**.

TAGS:

Image setting, image setup, iris control, P-IRIS



"Your Reliable Integrated Video Surveillance Solutions Provider"

Shenzhen Starlink Technology Co., Ltd.

1811, Block A, Zhantao Technology Building, Longhua District, P.R.China 518131

Email: info@qixingtechnology.com; qixing@qixingtechnology.com

<http://www.qixingtechnology.com>

©2009-2018 Shenzhen Starlink Technology Co., Ltd. All rights reserved.

*Product specifications and availability are subject to change without notice.